

FÅ DITT BONUS-BATTERI NÅ

Kampanjeperiode:
01.10.2025 - 31.03.2026



Kampanjekode „Battery25“

Kampanjemaskiner

 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE
■ DH18DPB Borhammer DH18DPBW2Z N. 56616522	■ DH1826DA Kombihammer DH1826DAW2Z N. 60058373	■ DH3628DA Kombihammer DH3628DAW2Z N. 600908989	■ DH3640DA Kombihammer DH3640DAW2Z N. 60058378	■ DS36DC Borskutrekker DS36DCW2Z N. 60046512
 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE
■ DS18DE Borskutrekker DS18DEW2Z N. 60046515	■ DS18DC Borskutrekker DS18DCW2Z N. 60046518	■ DV36DC Slagskutrekker DV36DCW2Z N. 60046521	■ DV18DC Slagbormaskin DV18DCW2Z N. 60046519	■ DV18DE Slagbormaskin DV18DEW2Z N. 60107799
 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE
■ WH18DE Slagskutrekker WH18DEW2Z N. 60031896	■ WH18DC Slagskutrekker WH18DCW2Z N. 60031893	■ WHP18DA Slagskutrekker WHP18DAW2Z N. 60654310	■ WH36DC Slagskutrekker WH36DCW2Z N. 60000291	■ WR18DH Muttertrekker WR18DHW2Z N. 60123304
 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE	 BATTERI KAMPANJE
■ WR36DH Muttertrekker WR36DHW2Z N. 60133151	■ WR36DE Muttertrekker WR36DEW2Z N. 57760984	■ WR36DB Muttertrekker WR36DBW2Z N. 54011595	■ WR36DG Muttertrekker WR36DGW2Z N. 60070077	■ WR36DF Muttertrekker WR36DFW2Z N. 60070074

Kampanjemaskiner

Kampanjeperiode 01.10.2025 - 31.03.2026

Kampanjekode "battery25"



 BATTERI KAMPANJE G1813DVE Vinkelsliper G1813DVEW2Z N. 60048149	 BATTERI KAMPANJE G18DSL2 Vinkelsliper G18DSL2W5Z N. 57197352	 BATTERI KAMPANJE G3613DVE Vinkelsliper G3613DVEW2Z N. 60050350	 BATTERI KAMPANJE G3613DVF Vinkelsliper G3613DVF2Z N. 60050355	 BATTERI KAMPANJE G3623DA Vinkelsliper G3623DAW4Z N. 55169100
 BATTERI KAMPANJE CJ36DB Stikksag CJ36DBW2Z N. 55989636	 BATTERI KAMPANJE CJ18DA Stikksag CJ18DAW2Z N. 56574102	 BATTERI KAMPANJE CJ18DB Stikksag CJ18DBW2Z N. 60070065	 BATTERI KAMPANJE SV1813DA Eksentersliper SV1813DAW2Z N. 60008497	 BATTERI KAMPANJE P18DSL Høvel P18DSLW2Z N. 53673060
 BATTERI KAMPANJE CR18DB Bajonetsag CR18DBW4Z N. 60019695	 BATTERI KAMPANJE CR18DMA Bajonetsag CR18DMAW2Z N. 60070068	 BATTERI KAMPANJE CR18DBL Bajonetsag CR18DBLW4Z N. 53673003	 BATTERI KAMPANJE CR36DA Bajonetsag CR36DAW4Z N. 55022732	 BATTERI KAMPANJE CR18DA Bajonetsag CR18DAW2Z N. 57151814
 BATTERI KAMPANJE M3612DA Overfres M3612DAW2Z N. 56577004	 BATTERI KAMPANJE C1806DB Sirkelsag C1806DBW2Z N. 60134028	 BATTERI KAMPANJE CD3605DB Metall Sirkelsag CD3605DBW2Z N. 60048134	 BATTERI KAMPANJE C3606DB Sirkelsag C3606DBW2Z N. 60070072	 BATTERI KAMPANJE C3606DUM Sirkelsag C3606DUMW2Z N. 60152690
 BATTERI KAMPANJE C3606DPA Dykksag C3606DPAW2Z N. 60058383	 BATTERI KAMPANJE C3609DUM Sirkelsag C3609DUMW4Z N. 60760696	 BATTERI KAMPANJE NR1890DCA Stavspikerpistol NR1890DCAW9Z N. 60654277	 BATTERI KAMPANJE NR1890DRA Stavspikerpistol NR1890DRAW9Z N. 60654289	 BATTERI KAMPANJE NT1865DA Dykkertpistol NT1865DAW6Z N. 57377486
 BATTERI KAMPANJE NV1845DA Coil Pappspikerpistol NV1845DAW6Z N. 60684996	 BATTERI KAMPANJE N1804DA Krampepistol N1804DAW6Z N. 60647976	 BATTERI KAMPANJE NC1840DA Betongspikerpistol NC1840DAW3Z N. 60760695	 BATTERI KAMPANJE NT1865DSA Dykkertpistol NT1865DSA9Z N. 60655662	 BATTERI KAMPANJE RB36DA Løvblåser RB36DAW4Z N. 55170443
 BATTERI KAMPANJE CS1810DD Grensag CS1810DDW4Z N. 60689177	 BATTERI KAMPANJE CS3630DC Kjedesag CS3630DCW4Z N. 60070073	 BATTERI KAMPANJE RA18DA Luftblåser RA18DAW4Z N. 60127146	 BATTERI KAMPANJE UR18DA Radio DAB+/FM UR18DAW4Z N. 57935443	 BATTERI KAMPANJE AL18DA Fettpresse AL18DAW4Z N. 60659025
 BATTERI KAMPANJE UB18DG Arbeidslampe UB18DGW4Z N. 60058385	 BATTERI KAMPANJE AC18DA Fugepistol AC18DAW5Z N. 60008490	 BATTERI KAMPANJE EC36DA Kompressor EC36DAW4Z N. 60133008	 BATTERI KAMPANJE UP18DA Luftpumpe UP18DAW4Z N. 60173273	 BATTERI KAMPANJE RH18DA Varmluftpistol RH18DAW2Z N. 60008477

Kampanjemaskiner

Kampanjeperiode 01.10.2025 - 31.03.2026

Kampanjekode "battery25"



PRODUKTLISTE	ARTIKKEL NUMMER
BETONGSPIKERPISTOL	NC1840DAW3Z
STAVSPIKERPISTOL	NR1890DCAW9Z
STAVSPIKERPISTOL	NR1890DRAW9Z
DYKKERTPISTOL	NT1865DAAW9Z
DYKKERTPISTOL	NT1865DSAW9Z
COIL PAPPSPIKERPISTOL	NV1845DAW6Z
MUTTERTREKKER	WR18DHW2Z
MUTTERTREKKER	WR36DBW2Z
MUTTERTREKKER	WR36DEW2Z
MUTTERTREKKER	WR36DFW2Z
MUTTERTREKKER	WR36DGW2Z
MUTTERTREKKER	WR36DHW2Z
SLAGSKRUTREKKER	WH18DCW2Z
SLAGSKRUTREKKER	WH18DEW2Z
SLAGSKRUTREKKER	WH36DCW2Z
BORSKRUTREKKER	DS18DCW2Z
BORSKRUTREKKER	DS18DEW2Z
BORSKRUTREKKER	DS36DCW2Z
SLAGBORMASKIN	DV18DCW2Z
SLAGBORMASKIN	DV18DEW2Z
SLAGBORMASKIN	DV36DCW2Z
VINKELSLIPER	G1813DVEW2Z
VINKELSLIPER	G18DSL2W3Z
VINKELSLIPER	G3613DVEW2Z
VINKELSLIPER	G3613DVF2W2Z
VINKELSLIPER	G3623DAW4Z
KOMBIHAMMER	DH1826DAW2Z
BORHAMMER	DH18DPBW2Z
KOMBIHAMMER	DH3628DAW2Z
KOMBIHAMMER	DH3640DAW2Z
BAJONETTSAG	CR18DAW2Z
BAJONETTSAG	CR18DBLW4Z
BAJONETTSAG	CR18DBW4Z
BAJONETTSAG	CR18DMAW2Z
BAJONETTSAG	CR36DAW4Z
SIRKELSAG	C1806DBW2Z
SIRKELSAG	C3606DBW2Z
DYKKSAG	C3606DPAW2Z
SIRKELSAG	C3606DUMW2Z
SIRKELSAG	C3609DUMW4Z
SIRKELSAG	CD3605DBW2Z
GRENSAG	CS1810DDW4Z
KJEDESAG	CS3630DCW4Z
STIKKSAG	CJ18DAW2Z
STIKKSAG	CJ18DBW2Z
STIKKSAG	CJ36DBW2Z
LUFTBLÄSER	RA18DAW4Z
LØVBLÄSER	RB36DAW4Z
GREASE GUN	AL18DAW4Z
RADIO	UR18DAW4Z
ARBEIDSLAMPE	UB18DGW4Z
FUGEPISTOL	AC18DAW5Z
VARMLUFTPISTOL	RH18DAW2Z
EKSENTERSLIPER	SV1813DAW2Z
LUFTPUMPE	UP18DAW4Z
KOMPRESSOR	EC36DAW4Z
KRAMPEPISTOL	N1804DAW6Z
OVERFRES	M3612DAW2Z
SLAGSKRUTREKKER, OIL PULSE	WHP18DAW2Z

Hikoki